#### § 98.33-5

as prescribed in \$153.900(d)(1) of this chapter.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990, as amended by CGD 97-057, 62 FR 51046, Sept. 30, 1997; USCG-2011-0088, 78 FR 54788, Sept. 6, 2013]

# §98.33-5 Portable tanks and IBCs authorized.

- (a) The cargoes authorized under §98.33–3 may be transferred to and from portable tanks to which this subpart applies if the portable tanks have:
- (1) A minimum design pressure of 9 psig.
- (2) Pressure-relief devices that may be frangible pressure-relief devices (rupture disks), and that do not open at less than 3 psig.
- (b) The cargoes authorized under §98.33–3 may be transferred to and from IBCs to which this subpart applies if the IBCs meet the requirements in §98.30–6.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990; 55 FR 47477, Nov. 14, 1990; USCG-2011-0088, 78 FR 54788, Sept. 6, 2013]

#### § 98.33-7 Pipe and hose connections.

If a portable tank or IBC authorized under §98.33–5 of this part has a pipe or hose connection in its bottom, the connection must have a manually operated valve and a bolted flange, threaded cap, or similar device, to protect against leakage of the tank's contents.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990, as amended by USCG-2011-0088, 78 FR 54788, Sept. 6, 2013]

#### § 98.33-9 Stowage.

Each portable tank or IBC authorized under §98.33-5 of this part must be secured to the vessel by devices of sufficient strength and number to prevent the tank from moving in any direction during transport.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990, as amended by USCG-2011-0088, 78 FR 54788, Sept. 6, 2013]

#### §98.33-11 Smoking.

No person may smoke when-

(a) Within 50 feet of a portable tank or IBC containing a combustible liquid; and

(b) On the deck where the tank or IBC is stowed.

[CGD 84–043, 55 FR 37412, Sept. 11, 1990, as amended by USCG–2011–0088, 78 FR 54788, Sept. 6, 20131

## § 98.33-13 Cargo-handling systems.

A cargo authorized under §98.33–3 of this part may not be transferred to or from a portable tank or IBC authorized under §98.33–5 of this part unless the cargo-handling system meets the requirements of subpart F of part 64 of this chapter.

[CGD 84–043, 55 FR 37412, Sept. 11, 1990, as amended by USCG–2011–0038, 78 FR 54788, Sept. 6, 2013]

# § 98.33-15 Transfers.

A cargo authorized under §98.33–3 of this part may not be transferred to or from a portable tank or IBC authorized under §98.33–5 of this part unless the following requirements are met:

- (a) Cargo pumps comply with §98.30-14 of this part;
- (b) *Ground connection* complies with §98.30-15 of this part;
- (c) Leakage containment complies with §98.30–17 of this part;
- (d) Qualification of person in charge complies with §98.30-18 of this part;
- (e) Supervision of person in charge complies with §98.30-19 of this part;
- (f) Transfers, general, comply with §98.30-23 of this part;
- (g) Connections comply with §98.30-27 of this part:
- (h) Pumping of incompatible products complies with §98.30-29 of this part;
- (i) Conditions for pumping comply with §98.30-31 of this part; and
- (j) Carriage of NLSs complies with §98.30-16 of this part.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990; 55 FR 47477, Nov. 14, 1990; USCG-2011-0088, 78 FR 54788, Sept. 6, 2013]

# PART 105—COMMERCIAL FISHING VESSELS DISPENSING PETROLEUM PRODUCTS

### Subpart 105.01—Administration

Sec.

105.01-1 Purpose.

105.01–3 Incorporation by reference.